



PUMPLOGIC

Quick Setup

First-Use Checklist

- 1. Connect power** — connect PumpLogic to a 12V or 24V power source, then press the power button on the left side of the device
- 2. Connect to WiFi** — scan the included **QR code sticker**, or open WiFi settings and connect to **PumpLogic-XXXX** (no password by default)
- 3. "No Internet" warning** — your phone may warn that the network has no internet. **Always choose to stay connected.** (See the WiFi Warning card for details.)
- 4. Open the dashboard** — in your browser, go to:
<http://192.168.4.1>
- 5. Verify the time is synced** — expand the **Network** card and check that **Last Sync** shows a timestamp. If it shows "Not synced," reload the page. (See the Setting the Time card.)
- 6. Review your settings** — expand the **Settings** card and configure for your installation:
 - **Temperature** — set trigger and direction (Trigger High for cooling, Trigger Low for freeze protection)
 - **Schedule** — set weekday and weekend operating hours
 - **Voltage** — enable for battery power, disable for constant power
 - **Pressure** — enable if a pressure sensor is installed

*Press **Save Settings** when done.*

- 7. Test the pump** — expand the **Manual Control** card, press **Force ON** to confirm the pump runs, then press **Force OFF** to

stop it.

Tip: *To prevent unauthorized access, you can set a WiFi password in the Network card. This is optional — PumpLogic works fine with an open network.*

Setup complete! PumpLogic will now operate automatically based on your settings.