



**PUMPLOGIC**

## Getting Started

---

### Connect to PumpLogic

1. On your phone, tablet, or computer, open **WiFi settings**
2. Look for the network named **PumpLogic-XXXX** (XXXX is unique to your device)
3. Connect to the network (no password by default)
4. Open a web browser and go to:

<http://192.168.4.1>

or <http://pumplogic.local>

---

### Important Notes

- PumpLogic creates its **own WiFi network** — it does not join your home or office WiFi.
  - **No internet access** while connected. Your phone may warn you — always stay on the network.
  - The IP address is always **192.168.4.1**
  - WiFi range is typically 30–100 ft (10–30 m) indoors.
- 

### Included in the Box

- **Quick Setup card** — first-use checklist, power-on to first pump test.
  - **QR Code stickers** — scan to open the Web Dashboard from any phone or tablet.
  - **Quick Access card** — QR codes for the User Guide, Web Dashboard, and PumpLogic website.
- 

Start with the **Quick Setup** card for a complete first-use walkthrough.